

Kinvaro L-80

Montageanleitung / Assembly instructions

F152147588898 - 05/2015

1

Montage / Assembling

Montage: Kinvaro L-80
Mounting: Kinvaro L-80
Montage: Kinvaro L-80

Montaggio: Kinvaro L-80
Montaje: Kinvaro L-80
Montering: Kinvaro L-80




L-80

Kinvaro L-80

Montageanleitung / Assembly instructions


F152147588898 - 05/2015

Montage / Assembling





Kinvaro L-80	KH	min. LH	A	Y
Typ 1	350 - 369	312	161	304
Typ 2	370 - 389	332	176	337
Typ 3	390 - 409	352	191	370
Typ 4	410 - 429	372	206	403
Typ 5	430 - 600	392	221	436


Alle Maße in Millimeter.
 All dimensions in millimetres.
 Toutes les dimensions sont en millimètres.
 Tutte le misure sono in millimetri.
 Todas las medidas en milímetros.
 Alla mått i millimeter.



Kinvaro L-80	1	2	3	4	5
X	190	210	230	250	270



Kinvaro L-80	1	2	3	4	5
X	190	210	230	250	270





Kinvaro L-80





Montageanleitung / Assembly instructions

F152147588898 - 05/2015







1



2



3





Kinvaro L-80

Montageanleitung / Assembly instructions




F152147588898 - 05/2015

Montage / Assembling







4



5



6



Kinvaro L-80




Montageanleitung / Assembly instructions

F152147588898 - 05/2015

8

Montage / Assembling

7



8

